

TIRE GAUGE INSTRUCTIONS

TIRE GAUGE

You can improve your gas mileage by around 3.3% by keeping your tires inflated to the proper pressure. Under-inflated tires can lower gas mileage by 0.4% for every 1 PSI drop in pressure of all four tires. Properly inflated tires are safer and last longer.

Proper Use:

- Check pressure before driving
- Make sure valve is free of dirt and debris
- Press gauge firmly onto valve stem and read PSI on indicator
- Reset dial by depressing pressure release button on side of unit
- Inflate tire to recommended pressure

NOTE: Do NOT over-inflate.

SPECIFICATIONS: PRESSURE RANGE: 5–60 PSI

MEDIDOR DE AIRE

Usted puede mejorar el rendimiento del combustible en alrededor del 3.3% al mantener sus llantas infladas a la presión indicada. Las llantas mal infladas pueden reducir el rendimiento de la gasolina en un 0.4% por cada disminución de 1 PSI en las cuatro llantas. Las llantas infladas correctamente son más seguras y duran más.

Instrucciones de Uso:

- Revisar la presión antes de manejar
- Asegurese que no haiga ningún objeto en la válvula
- Apriete el medidor en la válvula y lea el PSI (presión) en la varilla
- Reajuste el medidor presionando el boton de lanzamiento de la presion en el lado de la unidad.
- Infle a la presión recomendada

NOTA: NO sobre-infle.

ESPECIFICACIONES: RANGO DE PRESIÓN: 5–60 PSI