



# TALL INNOVATIVE EDGING

Patent Pending

Manufactured by



**ValleyView**  
Industries  
Setting the Landscape Industry Standard

13834 S. Kostner Ave. Crestwood, IL 60418

## EASY INSTALLATION

**PRE-INSTALLATION:** For easier installation, unravel and lay out on pavement in the sun for at least 3 hours. Longer on cooler/cloudy days.

### Step 1

Place edging on level soil, with the tabs facing towards the planting bed. You may attach landscape fabric to tabs.



WARNING:  
WEAR SAFETY GOGGLES  
USER AND BYSTANDER

### Step 2

Hammer in stakes, every 2 feet, through provided holes at a 45° angle. Use extra stakes on curves.



### Step 3

Backfill with mulch or other ground cover as desired.



If using a hacksaw or tin snip to cut edging, use protective gloves.



To attach two pieces, overlap tabs five inches. Insert one or two anchor stakes for long lasting connection.



NEED  
ADDITIONAL  
9" STAKES?

Go to the website you ordered this product from or go to [www.valleyviewind.com/poly-stakes/](http://www.valleyviewind.com/poly-stakes/)



Edge Planting Beds

Use Around Trees



To create a 90 degree right angle/ corner, overlap tab of both pieces. Stake together.



Made in USA

## We would like to hear from you!

Go online to the website that you purchased the product from and review our product. Also, tell us what you think about our product. We are looking for a five-star review; your opinion counts! We would love to see your project—send your photos to [info@valleyviewind.com](mailto:info@valleyviewind.com)

[www.valleyviewind.com](http://www.valleyviewind.com)